



bam Group

RULES FOR WORKING ON THE WORKS PREMISES



1. SCOPE

These rules apply to the entire works premises and are there for your own safety.

2. HAZARDS TO PEOPLE AND THE ENVIRONMENT



- CAUTION: Overlapping traffic and circulation routes for wheeled loaders, trucks and people; complete separation everywhere is impossible due to the manner in which the premises are built.
- People getting hit or run over by vehicles or vehicles colliding due to narrow and unclear areas where traffic is routed or circulates.
- Vehicles and machinery toppling over or overturning during loading and unloading operations.
- Vehicles falling off stockpiles while driving or operating there.
- Accident risk when driving with a raised dumper.
- Tripping, falling and slipping on traffic or circulation routes due to unevenness, slipperiness or obstacles.
- Risk of injury from falling objects and/or goods being transported.
- Danger due to machinery starting up automatically and the risk of being drawn into the machine.
- Hazards associated with sampling raw materials and asphalt mixes.



3. PROTECTIVE MEASURES AND GUIDANCE FOR ACTION



- Immediately report to the works personnel when you enter the company premises.
- The instructions of the works personnel are to be followed at all times.
- A hi-vis vest and safety shoes are to be worn at all times on the premises. Wearing a helmet is also compulsory when working on the premises.
- The works own vehicles and construction equipment is given right-of-way.
- The maximum speed for trucks on the premises is 10 km/h.
- Remaining in the danger zone around a wheeled loader and other vehicles is prohibited.
- Access to production areas and climbing stockpiles without permission and prior safety instruction is prohibited for all persons from outside the company.
- Trucks have to be securely parked in a stable position with the Tractor and trailer axles in line when tipping material.
- Only the designated tipping and loading points are to be used.
- Pay attention to stability and keep a safe distance from the edges of slopes and escarpments on stockpiles, plateaus and ascents. Safety distances up to 12.0 t GCW > 1.00 m, over 12.0 t GCW > 2.00 m.
- Vehicles are only allowed to be stopped, parked and exited when they are in plain view. Exiting a vehicle for any reason other than to carry out operational work is not permitted; under no circumstances are children allowed to exit the vehicle. Parents are liable for their children.
- After unloading, trucks are only allowed to drive with the dumper fully lowered.
- When collecting samples from truck beds, position the vehicle as instructed by the works personnel and switch off the engine. Driving is only to be resumed when the sampler has left the sampling platform and the driver has given the go-ahead for the vehicle to continue.
- There is a strict ban on alcohol on the entire works premises.



4. ACTION IN THE EVENT OF DANGER AND DISRUPTIONS

- Immediately report any kind of disruptions or incidents to the works personnel.

5. ACTION IN THE EVENT OF ACCIDENTS; FIRST AID



- Administer first aid, avoid danger to yourself.
- Call the emergency services: 112
- Secure vehicles.
- Report accidents to the works manager.



Also available online at:
www-bam-net.de/betriebsordnung

Date: 01/11/2023